

Transmisor




1. Frecuencia operativa: 433.92 MHz±500KHz
2. Frecuencia de IR soportada: 38KHz / 56KHz
3. Distancia recepción infrarrojos: ≤10m
4. Alimentación: 5V-100mA, o dos pilas tipo AA LR6 1.5V

Receptor

1. Frecuencia operativa: 433.92 MHz±200KHz
2. Frecuencia de IR de salida: 38KHz / 56KHz (Seleccionable)
3. Distancia máxima de emisión IR: ≤5m
4. Alimentación: 5V-100mA, o dos pilas tipo AA LR6 1.5V
5. Distancia máxima en horizontal sin barreras entre el transmisor y el receptor: ≤200m

Contenido de la caja

1. Cable USB x 2
2. Manual del usuario
3. Cable extensor de IR
4. Transmisor
5. Receptor



Transmitter

1. Operating frequency: 433.92 MHz $\pm$ 500KHz
2. Supported IR frequencies: 38KHz / 56KHz
3. Infrared reception distance: $\leq 10\text{m}$
4. Power: 5V-100mA, or two batteries type AA LR6 1.5V

Receiver

1. Operating frequency: 433.92 MHz $\pm$ 200KHz
2. Output IR frequencies: 38KHz / 56KHz (Selectable)
3. Maximum IR emission distance: $\leq 5\text{m}$
4. Power: 5V-100mA, or two batteries type AA LR6 1.5V
5. Maximum horizontal distance without barriers between the transmitter and receiver: $\leq 200\text{m}$

Package contents

1. USB cable x 2
2. User manual
3. IR extender cable
4. Transmitter
5. Receiver

