

## MODIG S firmware upgrade

### Necessary material:

- Modig S with version 6150 or higher
- USB 2.0 memory ;
- New firmware of MODIG S;
- PC;

### Previous steps:

- Download last firmware version available for your modulator MODIG S. You can find at: <http://www.ftemaximal.com>
- Unzip the file downloaded from the web site. It contains:
  - ITEPKG03.PKG

### Upgrading:

1. Copy the file ITEPKG03.PKG in the root directory of the USB 2.0 memory.
2. Safe extract the USB 2.0 memory from the computer.
3. If the modulator was on please, turn off the modulator.
4. Connect the USB 2.0 memory in the USB port of the modulator MODIG S.
5. Turn on the modulator. Show the led **Power** and led **Mode** are on.
6. After some seconds the led **Mode** is blinking. (**Please, don't turn off the modulator**)
7. When the led **Mode** is off wait at least 2 seconds and the upgrade will be finished.
8. Turn off the modulator.
9. Remove the USB 2.0 disk from the USB port of the modulator.
10. Turn on the modulator to boot with the new firmware.